

FX-DHP-5083

Suited to all standard transfer process professionally and accurately.



FX-DHP-5083

Double-Plated Pneumatic Heat Press Machine

Reliable and Hassle-free Technology

The FX-DHP-5083 heat press machine is the best solution to apply our decorative heat transfers or any other large embellishments needed for your garments. It can also be highly used to apply woven and embroidered patches, digital heat transfers and other adhesive trims with decorative purposes. It has been designed to operate using a vertical pneumatic, single hot plate and a double stamping station allowing you to save time and effort compared to other manually handled presses. Due to its construction and quality of components, it is a low maintenance machine that will potentially save you cost, increase efficiencies and ultimately contribute towards your bottom line.

Versatility of On-demand Application

The FX-DHP-5083 is a double-plated heat press machine that allows you to embellish your garments quickly, at your own pace and in your own location. It's designed to operate for small and large volumes. You can easily adjust pressure and temperature settings for natural and synthetic fabrics giving you the flexibility you require even more so if you have many brand programs running at the same time.

World-class Technical Support

Our specialized technical support teams are available to aid you upon request. Whether it's a scheduled maintenance visit or an emergency call, our in-country* teams are there to help you deliver.

*In-country where Finotex has production facilities.

FX-DHP-5083 Specifications


Effective area	16" x 20" (40 x 50 cm)
Maximum temperature	250°C / 485°F
Max. Dwell time	999 Seconds
Pressure	0-0.8 MPa (0-8 Bar/0-116Psi)
Voltage	110V
Power consumption	1.7 kw/h
Packing Box Dimensions	108 x 81 x 83 cm
Net weight	90.7 kg (200 pounds)
Gross weight	118 kg (260 pounds)

For more information on our offerings, please contact your Sales Representative.

OPERATING INSTRUCTIONS FOR FX-DHP-5083


1. Set temperature, dwell time & pressure settings as indicated by your heat transfer provider.
2. Place the fabric/garment on top of any of the worktop stations.
3. Place the transfer with design face-down on the place you want to transfer it.
4. Press both green buttons at the same time to slide the machine head down. Once it reaches the pre-set dwell time, the hot plate will lift up automatically.
5. Remove the fabric/garment from the heat press.
6. Remove the paper/film carrier following the settings as indicated by your heat transfer provider.
7. Turn off the machine when is not in use.

Control Panel



1. **PV** Display measured temperature.
2. **SV** Display the setting temperature.
3. **COUNTER** Keeps track how many transfers have been applied.
4. **SET** Function key, to change between menu options and fix a choice.
5. **AT** Down arrow key, to lower the range of the setting.
6. **TIME** UP arrow key, to upper the range of the setting.
7. **CLEAR** Circle key, to clear the chosen settings.

Temperature & Dwell Time Setting



1. Press **SET** key to enter temperature setting mode.
2. Press down or up arrow keys to setup the correct temperature.
3. Press **SET** key to change to time setting mode.
4. Press down or up arrow keys to setup the correct temperature.
5. Press **SET** key to change to temperature selection mode.
6. Press down or up arrow keys to choose between °C or °F scale.

CONTACT

A Global Company You Can Trust



FINOTEX USA
Corporate Headquarters
6942 NW 50th Street
Miami, FL 33166
T. 305.470.2400
F. 305.594.5883
infousa@finotex.com

FINOTEX MEXICO
Finos Textiles de México S.A. de C.V.
Prol. Saturno No. 456 Nave 20
Ciudad de Guatemala,
México, D.F., México 07700
T. 5255.2062.2461
F. 5255.2062.2462
infomexico@finotex.com

FINOTEX COLOMBIA
Finotex S.A.
Carrera 74 No. 77-50
Barranquilla, Atlántico, Colombia
T. 575.361.6100
F. 575.361.6100 Option 4
infocolombia@finotex.com

FINOTEX DOMINICANA
Finos Textiles Dominicana S.R.L.
ZF Lic. Victor Manuel Espailat Mera,
1ra. Etapa. Calle Jacagua,
Esq. Laguna Prieta, Manzana J #10
Santiago, Dominican Republic, 51074
T. 1.809.242.7474
F. 1.809.242.7070
infodominicana@finotex.com

FINOTEX HONDURAS
Finos Textiles de Centroamérica, S.A.
Zip Choloma II
Carretera a la Jutosa
Choloma, Cortés, Honduras
T. 504.2626.9000
F. 504.2626.9001
infohonduras@finotex.com

FINOTEX EL SALVADOR
Finos Textiles de El Salvador S.A. de C.V.
Km. 24 Carretera a Santa Ana,
Zona Franca Export Salva,
Bodega No.12BC Lourdes, Colón
La Libertad, El Salvador.
T. 503.2304.2300
F. 503.2304.2310
infoelsalvador@finotex.com

FINOTEX GUATEMALA
Avenida Hincapie 24-20 Zona 13
Ciudad de Guatemala,
Guatemala 01013
T. 502.5732.7451
502.2384.3315
F. 502.2384.3316
infoguatemala@finotex.com

FINOTEX NICARAGUA
Finos Textiles, S.A.
Km. 47.5 Carretera Tipitapa-Masaya
Parque Ind. Astro Nicaragua S.A.
Nave 21E
Managua, Nicaragua
T. 505.2295.4899
F. 505.2295.5042
infonicaragua@finotex.com

FINOTEX PERU
Finos Textiles del Perú S.A.
Lima, Perú
T. 511.99.402.9190
infoperu@finotex.com

FINOTEX - SHINING HONG KONG/CHINA
Dodo Yu - Director
Unit 1-2. 1/f., Block A, Vigor Industrial Bldg.,
14-20 Cheung Tat Rd., Tsing Yi. N.T., H.K.
T. 852.2618.7338
F. 852.2428.6038
infochina@finotex.com
infohongkong@finotex.com